

**INSTALLATION GUIDE OF METHANOL PIGGYBACK /
PRECISION GEN2 PLUG & PLAY GAUGE FOR 1.0L K10C Boosterjet Turbo I3**

NOTICE:

Please turn off ignition, put the car to sleep mode and start installation after ten minutes !



1 OP1 BOOST

2 OP2 MANIFOLD (GAUGE)

3 CAMSHAFT

